

TIKSONS

INSTRUCTION

1. Before use, add proper amount of water to the stainless-steel plate. The height of the water should not touch the heating element.

2. When the grill is used for the first time, there will be a slight smell and smoke, which is normal. After a few minutes, the smell and smoke will dissipate.

3. When griller is in use, do not place any heat absorbing sheet on the net, as it could damage the griller. Use a aluminium foil or wrap food in the foil for barbecue, to maintain flavour


4. The grill itself is smokeless.

5. Barbeque meat, seasoning or brush oil, that drips on the heating element will produce a small amount of sooth, this is a normal. It can be wiped clean after the element has cooled, avoid water on the element at all times.

6. In order to avoid smoke, please avoid element when sprinkling seasoning etc.

7. Please keep children away from a hot griller.

8. Please avoid direct contact with the griller when hot.



Technical Specifications:

Watt: 2250 Watts

Voltage: 220-230V 50Hz

Specification:

Brand: TIKSONS

Model: GR-507

Manufactured In China

**Add: 47 Voortrekker Street ,
Vereeniging , 1939**

Tel : 072 997 9769

071 371 8837

Email: Info@tiksons.com

www.tiksons.com